




Universal Replacement Parts Kit 1916H


For all RL Sprayers Excluding BackPacks and Hand Sprayers




For 1/4" hose, use 1/4" nut and push hose over the first barb; for 3/8" hose use the 3/8" nut and push hose over both barbs




Nozzle caps that attach directly to the wand: Poly adjustable and flat fan patterned nozzles



Poly Flat Fan Nozzle (yellow) for use only with Poly Nozzle Assembly




Poly Nozzle Assembly



Pump Cylinder Gasket



Connector Nuts; Use to attach wand to flow control of Poly Nozzle Assembly to wand



Also included are 2 o-rings (shown on wand)



Pump Cylinder Check Valve